



P.O. Box 670  
1107 Progress Street  
Sturgis, MI 49091 USA

Toll Free: 800-726-9367  
Phone: 269-651-2300  
Fax: 269-651-9326

Website: [www.OwensProducts.com](http://www.OwensProducts.com)  
Email: [Sales@OwensProducts.com](mailto:Sales@OwensProducts.com)

## Ford Transit 130" W.B. – Available Now!!



Available as long boards both sides: OC7497A-01, OC7497AB-01 & OC8497A-01 (aluminum pictures are of 148" wheelbase van), (use 10-1241 brackets – ordered separately) or Long passenger/Short driver: OC72409-01, OC72409B-01 & OC82409-01 (use 10-1242 brackets – ordered separately).

These are **NO DRILL** into the vehicle.

***Call and order yours today!***

<u>P/N</u>	<u>Description</u>	<u>Jobber</u>
OC72409-01	2015 Ford Transit 130" WB Short/Long	\$278.00
OC72409B-01	2015 Ford Transit 130" WB Short/Long - Black	\$331.00
OC82409-01	2015 Ford Transit 130" WB Short/Long	\$263.00
10-1242	Bracket kit for OC72409-01, OC72409B-01, OC82409-01 & 683494-01	\$136.00
OC7497A-01	2015 Ford Transit 130" WB Full Length both sides	\$375.00
OC7497AB-01	2015 Ford Transit 130" WB Full Length both sides - Black	\$438.00
OC8497A-01	2015 Ford Transit 130" WB Full Length both sides - Diamond Plate	\$295.00
10-1241	Bracket kit for OC7497A-01/OC7497AB-01, OC8497A-01 & 6894-01	\$163.00
6894-01	2015 Ford Transit 130" WB Full Length both sides	\$390.00
683494-01	2015 Ford Transit 130" WB Short/Long	\$307.00