

P.O. Box 670  
1107 Progress Street  
Sturgis, MI 49091 USA

Toll Free: 800-726-9367  
Phone: 269-651-2300  
Fax: 269-651-9326

Website: [www.OwensProducts.com](http://www.OwensProducts.com)  
Email: [Sales@OwensProducts.com](mailto:Sales@OwensProducts.com)

## Ford Transit 148" W.B. – Available Now!!



Available as long boards both sides: OC74114E-01, OC74114EB-01 & OC84114E-01 (use 10-1230 brackets – ordered separately) or

Long passenger/Short driver: OC72408-01 & OC72408B-01 (use 10-1231 brackets – ordered separately).

These are **NO DRILL** into the vehicle.

***Call and order yours today!***

<u>P/N</u>	<u>Description</u>
OC72408-01	2015 Ford Transit 148" WB Short/Long
OC72408B-01	2015 Ford Transit 148" WB Short/Long - Black
10-1231	Bracket kit for OC72408-01 & OC72408B-01
OC74114E-01	2015 Ford Transit 148" WB Full Length both sides
OC74114EB-01	2015 Ford Transit 148" WB Full Length both sides - Black
OC84114E-01	2015 Ford Transit 148" WB Full Length both sides - Diamond Plate
10-1230	Bracket kit for OC74114E-01/OC74114EB-01 & OC84114E-01